

SHINE

Floor Finish 18

ENVIROCHEM

425 Whitehead Avenue
South River, NJ 08882
Phone—732-238-6700
Fax—732-238-5590

SHINE is a metal cross-linked floor finish designed to meet the demands for fast drying, high gloss and good economics. **SHINE** can be buffed nightly to maintain the wet look without powdering. It is also durable enough for customers who are not buffing on a regular basis.

PROPERTIES

| | |
|---------------------------------------|-----------------------------|
| Solids | 18% min |
| Slip resistance, COF..... | >0.50 |
| Re-coatability, ASTM D315..... | Exceeds |
| Detergent Resistance, ASTM D179 | Exceeds |
| pH | 8.0-8.5 |
| Dry/Recoat Time..... | 30 min. |
| Freeze/Thaw, ASTM D3209 | Passes |
| Soil Resistance, ASTM D3206..... | Excellent |
| Coverage..... | Up to 3000 sq ft per gal |

Seller makes no warranty, expressed or implied, concerning the use of this product other than indicated on the label. Buyer assumes all risk of use and/or handling of this material when such use and/or handling

DIRECTIONS FOR USE

After the floor has been properly stripped and free of any floor finish, stripper, dirt or debris and is completely dry, you may start the application process.

1. Set up wet floor signs to avoid costly slip fall occasions.
2. Follow all label instructions and precautions on all chemicals.
3. Using a clean bucket and wringer mop (Cotton/Rayon combination), pour the floor finish into a bucket. Pour enough finish into the bucket to completely cover the mop. This prevents the mop from delivering an uneven or streaky appearance if the finish is not uniformly distributed throughout the mop.
4. Place the mop in the wringer; push down slowly as to release excess finish back into the bucket. You have the correct amount of finish on the mop when the mop stops dripping.
5. Keep the mop flat on the floor and turn it over as soon as you feel a slight dragging effect. This again will ensure a uniform coat.
6. Re-submerge mop as needed.
7. Allow 20 - 30 minutes drying time between each coat.
8. Three to four coats of finish are recommended for the optimal shine and wear.

BURNISHING AND RECOATING

The proper burnishing pad is key to keeping a beautiful floor. In high traffic areas, burnish and reapply finish as needed.

FOR IN BETWEEN

Use Distributor's Choice Spray Buff to keep your floor at their brightest in between your regular applications of floor finish.